

FloppyDTV T/C

Internal FireWire cable assembly guide

FireWire connectors on motherboard



This procedure is suitable only for expert users. Errors in handling cables and connectors on the motherboard may damage the motherboard or the FloppyDTV!!!


Some motherboards have one 10 poles connectors usually intended to bring the FireWire connection to a Front or Back Panel.

This connector can also be used to connect the FloppyDTV with the special FireWire you find in the box with the FloppyDTV.

- Locate the FireWire (IEEE1394) connector on the motherboard referring to the "User Manual" of your motherboard.
- Search the pin-out of the connector on the User Manual of your motherboard and verify that it matches the following tables.



Use the motherboard connector only if you are sure that the pin-out matches the pin-out in the following tables! The motherboard can be damaged if the pin-out doesn't match!!!



IEEE1394

Pin	
1	TPA +
2	TPA -
3	GND (Ground)
4	GND (Ground)
5	TPB +
6	TPB -
7	V+
8	V+
9	NOT USED
10	GND (Ground)

- Turn OFF your computer!!! Unplug all the cables from the FloppyDTV
- Disassemble the Aluminium Housing from the FloppyDTV
- Unplug the FireWire cable from the FloppyDTV
- Plug the special FireWire Cable to the FloppyDTV
- Carefully identify the Pin1 of the FireWire connector on the Motherboard and plug the 10 Poles connector to the motherboard matching the Pin 1 of the cable to the Pin 1 of the motherboard.
- Plug again all the remaining cables on the FloppyDTV
- Your system can now be restarted



Don't use any different FireWire cable from that one supplied with the FloppyDTV to connect it to the motherboard!!!